

### Federal Reference Method (FRM)

- Sampler draws ambient air at a constant volumetric flow rate through a specially shaped inlet and inertial particle size separator to collect particles ≤ 2.5 microns onto a filter
- Each filter weighed before and after sampling. This requires a specialized laboratory
- FRMs Comprised entire LMAPCD PM<sub>2.5</sub> regulatory network for over a decade
  - Limited technology but reliable instruments
  - One 24-hr measurement every 3 days (non-continuous)
  - Expensive and laborious quality assurance requirements



#### **Federal Equivalent Methods**

- Met One BAM 1020
  - Beta Attenuation Method employing the absorption of beta radiation by solid particles extracted from air flow and measured on a glass fiber filter tape.
  - Introduced to LMAPCD network in 2010.
  - Provides hourly PM2.5 concentrations and could be utilized for the Air Quality
     Index as well as regulatory monitoring.
  - Initially easy to operate, but ...
    - Found some variability in data between like instruments
    - Required lengthy background tests to adjust for noise
    - Some issues with filter tape



#### Federal Equivalent Methods

- API Teledyne T640(x)
  - Measures PM mass using scattered light spectrometry
  - Introduced to LMAPCD network in 2018.
  - Provides continuous PM<sub>2.5</sub> concentrations and could be utilized for the Air Quality Index as well as regulatory monitoring.
    - Can even provide sub-hourly PM concentrations (e.g. 1-minute averages)
  - Does not require background (noise) testing.
  - Easier to operate than FRM and BAM, but does contain its own operational challenges






#### **Assessing Particulate Matter Methods**


#### Collocation


- Refers to the operation of particulate instruments side by side to assess the repeatability / variability of the data to evaluate the precision of the method
- Required for quality assurance purposes, but APCD has performed additional collocation studies to better evaluate methods






# **APCD PM**<sub>2.5</sub> Collocation Results










### **PM<sub>2.5</sub> Collocation Results Summary**


- T640 collocation results show excellent repeatability
- T640 repeatability / precision in line with FRM method
- T640 combines the reliability of the FRM method with the BAM 1020's continuous nature and ease of use
- While T640(x) precision seems to be excellent, there are some seasonal differences between T640 and FRM data




#### T640(x) vs FRM Collocation



## **Interpreting PM<sub>2.5</sub> Trends**





FRM data show a reduction in PM<sub>2.5</sub> of about 2 µg/m<sup>3</sup> over the last 7 years

When combining FRM & T640\* data, the  $PM_{2.5}$  reduction is about 1  $\mu g/m^3$  over the last 7 years



#### **Summary & Takeaways**

- APCD has evaluated several different particulate monitoring methods over the years and transitioned from FRMs to continuous methods
- The FRMs and T640s have shown the best repeatability / precision
- T640s provide several advantages over the older FRM method
  - Greater temporal representativeness (i.e. data available from all days)
  - Better understanding of diurnal profiles for particulate
  - Better understanding of the impact of short term spikes in PM on the 24-hour average
  - Ability to more easily relate changes in PM concentrations to meteorological events or emissions events
- Some differences in data do exist between T640s and FRMs
  - Some debate within air monitoring community regarding which method is more accurate
- Changes in monitoring methods can have a small impact on assessing trends



#### Questions

Tom Lobb, Air Monitoring Project Supervisor – <a href="mailto:Tom.Lobb@louisvilleky.gov">Tom.Lobb@louisvilleky.gov</a>

Bryan Paris, Data Analyst & QA/Toxics Supervisor – <a href="mailto:Bryan.Paris@louisvilleky.gov">Bryan.Paris@louisvilleky.gov</a>

Billy DeWitt, Air Monitoring Program Manager – Billy.Dewitt@louisvilleky.gov

